



INSTRUCTIONS: RUSSIAN CROSSFIRE MONITOR TOP FINAL ASSEMBLY

Install the Handle: Apply Red Loctite (adhesive #271) to Socket Head Cap Screw threads and use it to attach the Peg to the "Tombstone".

Install the Pressure Gage & Bumper Assembly by screwing it into the Big Bend Casting.

Install the Warning Label into the recess in the top of the Gearbox.



TASK FORCE TIPS, INC.
MADE IN USA • www.tft.com

3701 Innovation Way, Valparaiso, IN 46383-9327 USA
800-348-2686 • 219-462-6161 • Fax 219-464-7155