

Lever Style Vent-Drain Installation Instructions

1. Apply Loctite 545 Thread Sealant (provided) to the 3/4" threads on the Vent-Drain body.
2. Screw the Vent-Drain body into the 3/4" NPT hole in the casting.
3. Apply Thread Sealant, pipe dope, or Teflon tape to the threads on the 1/2" hose barb fitting.
4. Screw the 1/2" hose barb fitting into the hole in the Vent-Drain body.

VERY IMPORTANT:

LEAVE A MINIMUM OF 1-3/8" (35mm) OF THE BARB FITTING VISIBLE.
(If the barb fitting is screwed in too far, the lever will be difficult or even impossible to turn.)



For questions regarding troubleshooting, parts, or repair, contact your local dealer or TFT's service department.