



INSTRUCTIONS: RUSSIAN MONSOON RC FINAL ASSEMBLY



Install the 2 Manual Override Knobs using 2 Button Head Cap Screws per knob.

Apply Blue Loctite (Adhesive #242) on threads of each Cap Screw before installation.

TASK FORCE TIPS, INC.
MADE IN USA • www.tft.com

3701 Innovation Way, Valparaiso, IN 46383-9327 USA
800-348-2686 • 219-462-6161 • Fax 219-464-7155